



Automatic Launching of Clarinet Profile

Related Version

Clarinet Run Time Software V8.

Manager-Dialogue Program Configuration

The direct command is: **wac_md -r[profile.acp] -x**

The command supports the following options:

- **-r**: to launch the last current profile (edited or executed) in the working directory.
- **-rprofile.acp**: to launch the profile defined in the working directory. The .acp suffix is optional.
- **-x**: the Manager is closed at the end of profile execution.

Command File

The start.bat command file presented hereafter allows the Clarinet Loader to be executed before the execution of the current profile in a Clawork directory (Clarinet version installed with the C:\Clarinet path).

```
cd C:\Clarinet\Clawork                (working directory)
start /w C:\Clarinet\Clatools\wac_load.exe (launched in spawn mode)
start C:\Clarinet\Clatools\wac_md.exe -r -x
```

A shortcut to the start.bat command file can replace the Clarinet Loader shortcut in the **Start** group if the operator requires an automatic start up.

